




End Wall Model# EWC4040DTR

For Shipping Container Roof
Double Truss Round Style 40'x40'x15'

Assembly Instructions







Equipment List

Speed Wrench 22#.23#.24#	
Hammer (30lb)	
Rope (12#)	tzhuarul.cn.alibaba.com
Long Tape (50m)	
Hammer Drill*1	
Lifter*2	
Crane*1	
Forklift*1	
Protective equipment	





YOU MUST READ THIS DOCUMENT BEFORE YOU BEGIN TO ASSEMBLE THE SHELTER.

Thank you for purchasing our shelter. When properly assembled and maintained, this product will provide years of reliable service. These instructions include helpful hints and important information needed to safely assemble and properly maintain the shelter. Please read these instructions **before** you begin.

If you have any questions during the assembly, please contact local dealer for assistance.

SAFETY PRECAUTIONS

- . Wear eye protection.
- . Wear head protection
- . Wear gloves when handling metal tubes
- . Use a portable GFCI (Ground Fault Circuit Interrupter) when working with power tools and cords.
- . Do not climb on the shelter or framing during or after construction.
- . Do not occupy the shelter during high winds, tornadoes, or hurricanes.
- . Provide adequate ventilation if the structure is enclosed.
- . Do not store hazardous materials in the shelter.
- . Provide proper ingress and egress to prevent entrapment.

ANCHORING INSTRUCTIONS

Prior to assembling this shelter, please read the MUST READ document included with the shipment.

WARNING: The anchor assembly is an integral part of the shelter construction. Improper anchoring may cause shelter instability and failure of the structure. Failing to anchor the shelter properly **will void the manufacturer's warranty** and may cause serious injury and damage.

LOCATION

Choosing the proper location is an important step before you begin to assemble the structure.

The following suggestions and precautions will help you determine whether your selected location is the best location.

- . Never erect the structure under power lines.
- . Identify whether underground cables and pipes are present *before* preparing the site or anchoring the structure.
- . Location should be away from structures that could cause snow to drift on or around the building
- . Do not position the shelter where large loads such as snow and ice, large tree branches, or other overhead obstacles could fall.
- . Your shelter's cover can be quickly removed and stored prior to severe weather conditions. If strong winds or severe weather is forecast in your area, we recommend removal of cover.

SITE

After choosing a location, proper preparation of the site is essential. The following site characteristics will help ensure the integrity of the structure.

- . The support structure must be level to properly and safely erect and anchor the frame.
- . Drainage: Water draining off the structure and from areas surrounding the site should drain away from the site to prevent damage to the site, the structure, and contents of the structure.

WARNING: The individuals assembling this structure are responsible for designing and furnishing all temporary bracing, shoring and support needed during the assembly process. For safety reasons, those who are not familiar with recognized construction methods and techniques *must seek the help of a qualified contractor*.






ANCHORING THE CONTAINER

Make sure you have:

- Welder.
- Cement.
- Four 3" x 3" x 6 feet ¼" Square steel angle
- 1. As shown in the diagram 1, make a 3 ft deep hole right beside one of the front and opposite rear corners of the container, in which the 6ft <u>square steel</u> will be installed.
- 2. Insert the 6ft <u>square steel</u> into the hole, making sure 3ft is below the surface completely laying on the side of the containers.
- 3. Weld the *square steel* to the 2 containers.
- 4. Pour cement in the holes to make sure the *square steel* won't move.
- 5. Repeat the previous steps on the corners located in the opposite rear side.

Securing the containers to the floor is crucial, that way the containers won't shift under harsh weather conditions, thus avoiding the shipping container canopy roof top of getting damaged.






Diagram 1





Highly Recommended

- 1. All container canopy covers need to be removed during windstorm of 60 mph, leaving frame assembled. Customer responsibility.
- 2. All container canopy covers need to be removed before a snowstorm of 1-2 inches (for single truss Shipping container roofs) and 3-4 inches (for double truss Shipping container roofs), leaving the frame assembled. Customer responsibility.
- **3.** It is highly recommended for customers who live in snow states and cities to use double truss framing instead of Single truss framing. Customer responsibility.
- **4.** It's the owner's responsibility to shovel snow off the canopy rooftop.
- 5. All containers need to be anchored to the ground in each opposite corner sides. Customer responsibility.
- **6.** All of our products fall under the temporary structure category/storage ragtops.

Return Policy: Any product can be returned within 7 calendar days after arrival; shipping expenses are not refundable. For more information, please refer to the **Return and refund policy** page.

About lifespan:

Tarp lifespan: 7-10 years*
Frame Lifespan: +15 years*

*The term "lifespan" refers to the durability of the materials themselves, not to the structural integrity of the canopy once assembled.



+1 (321) 710-0804

www.storageandcanopy.com

End Wall 40'x40'x15' Parts List

Part			Qty/
Code	Description		
21	left lower post welded with door track		1
22	right lower post welded with door track		1
23	middle post welded with door track (extension for high cube container)	###F	2
24	left upper post welded with door track and pully		1
25	right upper post welded with door track and pully	#	1
26	upper post	11 1	2
27	connection plate for post	110	6+6
28	interior lower post		2
29	interior middle post (extension for high cube container)	———	2
30	interior upper post, left & right	<u> </u>	2
30A	base plate		2
31	cross beam, 2pcs/set	E ##3	1 set
32	vertical rod	6	1
33	rail	C	2
34	rail	с	8
35	rail	G	4
36	side square tube (left & right) with velcro		2
37	side square tube with velcro (extension for high cube container)		2
38	door winch bracket	<i>₹</i>	1
39	support tube for winch bracket	€=====	1



990 U.S. 27 Venus, FL 33960 United States sales@storageandcanopy.com

+1 (321) 710-0804

40	pole for door opening		1
41	door bracing tube 2pcs/set	FILE	5 sets
42	bottom bracing tube with hole 2pcs/set		1 set
43	tube clip with bolt		11
44	bolt M12x130 for post		26
45	bolt M10x70 for post		25
46	bolt M10x30 for connection plate		22
47	bolt M10x90 for swaged tube		12
48	bolt M8x70 for rail		2
49	carriage bolt M12x100 for rail		6
50	bolt M6x40 for door bracing tube No.41, No.42		6
51	expansion bolt		16
52	cable tie	()	60
53	rope, 5 bundles		2 packs
54	steel wire rope		1 bundle
55	steel wire clamp		4
56	door winch		1
57	front cover		1






FRAME INSTALLATION

Installation for End Wall Basing on 40ft standard container (8'6" high)

Winch door size: W13ft x H16ft








Installation for End Wall Basing on 40ft high cube container (9'6" high)


Winch door size: W13ft x H17ft








WINCH DOOR INSTALLATION






- 1. Install the front door frame and door winch bracket
- 2. Fix the winch to the bracket. Make sure the winch handle faces the outside. Refer to Figure 1.





990 U.S. 27 Venus, FL 33960 United States
 sales@storageandcanopy.com
 +1 (321) 710-0804


- 3. Take out the door curtain cloth and lay it on the ground. Pay attention to the direction. The side with pipe pockets faces inward.
- 4. Connect the door bracing tube (2pcs/set) with M6x40 bolt.
- 5. Thread the door bracing tube into the pocket from top to bottom. Pay attention to the bottom bracing tube. There are holes on both sides for fixing steel wire rope. Refer to Figure 2.





990 U.S. 27 Venus, FL 33960 United States
 sales@storageandcanopy.com
 +1 (321) 710-0804

- 6. Put the steel wire rope through the pulley on the door frame as shown in Figure 3, so that the steel wire rope is located on the inner side of the door frame and on the same plane as the pulley, and then the steel wire rope sags naturally. Keep the length of both sides equal, and naturally sag to the ground.
- 7. Fix each end of steel wire rope to the hole on bottom bracing tube with steel wire clamps. Make sure fix it firmly.
- 8. Put the door bracing tube into the track from the gap at the bottom, from top to bottom.






990 U.S. 27 Venus, FL 33960 United States
 sales@storageandcanopy.com
 +1 (321) 710-0804

www.storageandcanopy.com

9. Adjust the length of the steel wire rope to be equal on both sides. Fix the wire rope fold to the hole in the winch. Refer to Figure 4.










10. Turn the winch clockwise to lift the door curtain cloth and bracing tubes to a position about40-50cm away from the cross beam. Lace the eyelets on the cloth to cross beam with a rope. Refer toFigure 5.






990 U.S. 27 Venus, FL 33960 United States sales@storageandcanopy.com
+1 (321) 710-0804

www.storageandcanopy.com

11. Now the winch door installation is completed. Turn the winch clockwise to raise and counterclockwise to lower the door. The steel wire rope shall be evenly wound on the winch so that the door can rise and fall smoothly.








COVER INSTALLATION

Installation for End Wall Basing on 40ft standard container (8'6" high)

Winch door size: W13ft x H16ft

Note: Need to put the bottom bracing tube(No.42) into the second last row of pocket.






Installation for End Wall Basing on 40ft high cube container (9'6" high)

Winch door size: W13ft x H17ft

Note: Need to put the bottom bracing tube(No.42) into the bottom pocket.



Now your installation is completed.